# User's Manual



### SYSTEM CONNECTION

 Connect the battery to the charge regulator - plus and minus.it will detect the battery voltage and goes to charging progress.
Connect the photovoltaic module to the regulator - plus and minus.
Connect the consumer to the charge regulator - plus and minus.
The reverse order applies when deinstalling!
An improper sequence order can damage the controller!

### SAFETY INSTRUCTIONS

 Make sure your battery has enough voltage for the controller to recognize the battery type before first installation.
The battery cable should be as short as possible to minimize loss.
The regulator is only suitable for lead acid batteries: OPEN,AGM, GEL it is not suited for nickel metal hydride, lithium ions or other batteries.
The charge regulator is only suitable for regulating solar modules. Never connect another charging source to the charge regulator.

## **PRODUCT FEATURES**

1.Build-in industrial micro controller.


2. Input and output LED display,asimple 4-stage battery capacity indicator.

3.Fully 4-stage PWM charge management.

4.Build-in short-circuit protection,open-circuit protection,reverse protection,over-load protection.

5.Dual mosfet Reverse current protection ,low heat production.

6.Model XTD1210/XTD1220 is equiped with USB cell phone charger.



#### **TROUBLE SHOOTING**

Situation	Probable cause	Solution	
Charge LED not on	Solar panel opened	Reconnect	
when sunny	or reversed		
Load LED off	Battery low	recharge	
Load LED slow flashing	Over load	Reduce load watt	
Load LED slow flashing	Short circuit protection Auto reconnect		
Power off	Battery too low/reverse	Check battery/connection	

## **TECHNICAL PARAMETER**

MODEL	XDC1210	XDC1220		
Batt voltage	12V/24V			
Charge current	10A	20A		
Discharge current	10A	20A		
Max Solar input	42V			
Charge drop	<0.2V			
Discharge drop	<0.25V			
Equalization	14.8V			
Bulk	14.5V			
Acceptance	14.2V PWM			
Float	13.8V			
Charge reconnect	13.0V			
Discharge stop	11.2V			
Discharge reconnect	12.6V			
Self-consume	<10mA			
Temperature compensation	N/C			
USB output	5V 0.8A		N/C	
Operating temperature	-35~+60 °C			
Size/Weight	133*70*35mm /150g			

\*all red color voltage X2 while using 24V system

\*Product specifications are subject to change without prior notice